


# LYNX Series Battery Replacement

1. Press top tabs with screwdriver then pull front face-plate down



2. Remove battery holder screw then unplug battery from circuit board and remove.



3. Re Install new battery, Screw in battery holder and close system.

**Honeywell LYNXRCHKIT-SC 7.2 Volt 1100 mA battery is available from**

- Batteries+Bulbs stores
- Amazon.com
- Ebay.com
- Walmart.com

